


CHARGER BMS16Pro connection diagram for 16S LiPo/LiFe/LiTO battery pack

16 CELLS Connected in series first and then connect to BMS16Pro



● Cell positive ● Cell negative

